



www.atsdesign.com

2015 ATS Design Application Guide

Questions?
info@atsdesign.com

YEAR	Vehicle Make / Model	BRK KIT C810	MX C110	E2 C310	SL C410	EDGE C610	UNI C810
Acura							
02-06	MDX (Need to remove mud flap)	C810-BRK-81	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
07-09	MDX (UNLIGHTED)	C810-BRK-132	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
10-13	MDX	C810-BRK-132	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
08-11	RDX (UNLIGHTED)	C810-BRK-131	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
Buick							
03-07	Rainer (Unlighted)	C810-BRK-10	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
05-07	Terraza Van Long Wheel Base (Unlighted)	C810-BRK-99	C110-CU86	N/A	C410-CU86	C610-CU86	C810-CU86
05-07	Terraza Van Short Wheel Base (Unlighted)	C810-BRK-99	C110-CU80	N/A	C410-CU80	C610-CU80	C810-CU80
Chevrolet							
02-04	Avalanche w/cladding (Unlighted)	C810-BRK-09	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
03-04	Avalanche	C810-BRK-09	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
05-13	Avalanche w/cladding (Unlighted)	C810-BRK-119A	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
05-13	Avalanche	C810-BRK-119A	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
10-12	Equinox (Unlighted)	C810-BRK-160	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
99-06	Silverado 1500 STD.Cab (No SS model)	C810-BRK-16S	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
99-06	Silverado EXT.Cab (No SS model)	C810-BRK-16	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
01-06	Silverado HD2500 Crew Cab	C810-BRK-17	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
04-06	Silverado HD1500 Crew Cab	C810-BRK-17A	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
07-15	Silverado Standard Cab Gasoline & Diesel	C810-BRK-130	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
07-15	Silverado Extended Cab Gasoline & Diesel	C810-BRK-130	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-15	Silverado Crew Cab Gasoline & Diesel	C810-BRK-126	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
11-15	Silverado HD Extended Cab Diesel	C810-BRK-169	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
11-15	Silverado HD Crew Cab Diesel	C810-BRK-169	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
05-15	Suburban 1500/2500	C810-BRK-119A	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
05-15	Tahoe	C810-BRK-119	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
02-09	Trailblazer	C810-BRK-10	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
05-09	Uplander Van Long Wheel Base (UNLIGHTED)	C810-BRK-99	C110-CU86	N/A	C410-CU86	N/A	C810-CU86
05-09	Uplander Van Short Wheel Base (UNLIGHTED)	C810-BRK-99	C110-CU80	N/A	C410-CU80	N/A	C810-CU80
Chrysler - Dodge							
07-09	Aspen	C810-BRK-93	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
00-04	Dakota Crew Cab	C810-BRK-07	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
05-11	Dakota EXT.Cab	C810-BRK-116	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
05-11	Dakota Crew Cab	C810-BRK-116	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
04-09	Durango	C810-BRK-93	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
Chrysler - Dodge							
08-14	Journey (UNLIGHTED)	C810-BRK-171	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-12	Nitro	C810-BRK-129	C110-CU62	N/A	C410-CU62	C610-CU62	N/A
02-08	Ram STD Cab	C810-BRK-08S	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
02-09	Ram 2500/3500 Quad Cab	C810-BRK-08	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
02-08	Ram EXT Cab	C810-BRK-08	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
06-09	Ram Mega Cab HD 2500/3500	C810-BRK-08	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
09-15	Ram STD. Cab	C810-BRK-151	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
09-15	Ram Quad Cab	C810-BRK-151	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
09-15	Ram Crew Cab	C810-BRK-151	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
09-15	Ram Mega Cab	C810-BRK-151	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
07-15	Sprinter Van (Front Doors only)	C810-BRK-124	C110-CU36	N/A	C410-CU36	C610-CU36	N/A



www.atsdesign.com

Questions?
info@atsdesign.com

2015 ATS Design Application Guide

YEAR	Vehicle Make / Model	BRK KIT C810	MX C110	E2 C310	SL C410	EDGE C610	UNI C810
Ford							
92-15	E-Series Van	C810-BRK-35	C110-CU102	N/A	C410-CU102	C610-CU102	N/A
00-05	Excursion	C810-BRK-25	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
97-06	Expedition	C810-BRK-21	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU90
07-15	Expedition	C810-BRK-127	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-15	Expedition EL	C810-BRK-127	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
91-01	Explorer (No Factory Side Skirts)	C810-BRK-22	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
06-10	Explorer 4 door	C810-BRK-122	C110-CU70	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-10	Explorer Sport trac	C810-BRK-122	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
11-14	Explorer	C810-BRK-170	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
04-14	F150 STD. Cab	C810-BRK-89	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
04-14	F150 Supercab	C810-BRK-91	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
04-08	F150 Supercrew	C810-BRK-90	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
09-14	F150 Supercrew	C810-BRK-90	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
99-15	Super Duty STD. Cab	C810-BRK-24	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
99-15	Super Duty EXT. Cab	C810-BRK-24	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
99-15	Super Duty Crew Cab	C810-BRK-25	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
GMC							
02-09	Envoy	C810-BRK-10	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
99-04	Sierra EXT. Cab	C810-BRK-16	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
99-06	Sierra 1500/2500 EXT.Cab	C810-BRK-16	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
01-06	Sierra Crew Cab	C810-BRK-17	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
04-06	Sierra 1500 Crew Cab 5'.5" Short Bed	C810-BRK-17A	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
07-15	Sierra Standard Cab <i>Gasoline & Diesel</i>	C810-BRK-130	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
07-15	Sierra Extended Cab <i>Gasoline & Diesel</i>	C810-BRK-130	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-15	Sierra Crew Cab <i>Gasoline & Diesel</i>	C810-BRK-126	C110-CU86	N/A	C410-CU86	C610-CU86	C810-CU86
11-15	Sierra Extended Cab <i>Diesel</i>	C810-BRK-169	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
11-15	Sierra Crew Cab <i>Diesel</i>	C810-BRK-169	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
05-15	Yukon	C810-BRK-119	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
05-14	Yukon XL	C810-BRK-119A	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
Honda							
02-07	CR-V (Remove mud flap) (UNLIGHTED)	C810-BRK-80	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
08-10	CR-V (UNLIGHTED)	C810-BRK-131	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
11-15	CR-V (UNLIGHTED)	C810-BRK-133	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
03-08	Pilot (Remove mud flap) (Unlighted)	C810-BRK-81	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
09-15	Pilot	C810-BRK-132	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
06-14	Ridgeline	C810-BRK-75	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
Hyundai							
07-09	Santa Fe (Unlighted)	C810-BRK-135	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
10-12	Santa Fe	C810-BRK-135	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
Infiniti							
2013	JX35 (Unlighted boards only)	C810-BRK-175	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
14-15	QX60	C810-BRK-175	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
Isuzu							
03-08	Ascender	C810-BRK-10	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
Jeep							
06-10	Commander	C810-BRK-123	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
02-07	Liberty	C810-BRK-56	C110-CU67	N/A	C410-CU67	C610-CU67	N/A
08-12	Liberty	C810BRK-129	C110-CU62	N/A	C410-CU62	C610-CU62	N/A
Kia							
11-13	Sorento EX / LX models only (UNLIGHTED)	C810-BRK-165	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
11-13	Sorento SX models only (UNLIGHTED)	C810-BRK-165	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
10-15	Sportage (UNLIGHTED)	C810-BRK-166	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69



www.atsdesign.com

Questions?
info@atsdesign.com

2015 ATS Design Application Guide

YEAR	Vehicle Make / Model	BRK KIT C810	MX C110	E2 C310	SL C410	EDGE C610	UNI C810
Lincoln							
06-08	Mark LT	C810-BRK-90	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
2015	Navigator	C810-BRK-127	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90
Mercury							
06-10	Mountaineer	C810-BRK-122	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
Mitsubishi							
06-08	Raider EXT. Cab	C810-BRK-116	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
06-08	Raider Crew Cab	C810-BRK-116	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
Nissan							
05-15	Armada	C810-BRK-88	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
13-15	Pathfinder (UNLIGHTED BOARDS ONLY)	C810-BRK-175	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
04-10	Quest	C810-BRK-121	C110-CU86	C310-CU86	C410-CU86	C610-CU86	N/A
04-15	Titan Crew Cab	C810-BRK-88	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
04-15	Titan King Cab	C810-BRK-88	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
Oldsmobile							
02-04	Bravada	C810-BRK-10	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
Pontiac							
05-06	Montana SV6 Van (Unlighted)	C810-BRK-99	C110-CU86	C310-CU86	C410-CU86	C610-CU86	C810-CU86
Saturn							
05-07	Relay Van Long Wheel Base (Unlighted)	C810-BRK-99	C110-CU86	N/A	C410-CU86	N/A	C810-CU86
05-07	Relay Van Short Wheel Base (Unlighted)	C810-BRK-99	C110-CU80	N/A	C410-CU80	N/A	C810-CU80
Toyota							
03-09	4Runner (UNLIGHTED)	C810-BRK-47	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
10-15	4Runner Trail / SR5 (No Appearance Package)	C810-BRK-47	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
10-14	4Runner Limited/ SR5 (Appearance Pkg Only)	C810-BRK-147	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU69
07-14	FJ	C810-BRK-47	C110-CU62	N/A	C410-CU62	C610-CU62	N/A
01-07	Highlander	C810-BRK-44	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
08-13	Highlander	C810-BRK-140	C110-CU70	C310-CU70	C410-CU70	C610-CU70	N/A
2015	Highlander	TBA					
06-12	Rav-4	C810-BRK-125	C110-CU70	N/A	C410-CU70	N/A	N/A
01-07	Sequoia (Unlighted boards only)	C810-BRK-43	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
08-15	Sequoia (Unlighted boards only)	C810-BRK-145	C110-CU80	C310-CU80	C410-CU80	C610-CU80	N/A
04-10	Sienna Van	C810-BRK-96	N/A	N/A	C410-CU84	N/A	N/A
11-15	Sienna Van (Excludes: SE models)	C810-BRK-168	C110-CU86	N/A	C410-CU84	N/A	N/A
99-04	Tacoma STD.	C810-BRK-40	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
99-04	Tacoma Access Cab	C810-BRK-40	C110-CU70	N/A	C410-CU70	C610-CU70	C810-CU69
05-15	Tacoma STD Cab (UNLIGHTED)	C810-BRK-100	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
05-15	Tacoma Access Cab (UNLIGHTED)	C810-BRK-100	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
05-15	Tacoma D-Cab (UNLIGHTED)	C810-BRK-100	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
00-06	Tundra STD.	C810-BRK-42	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
00-06	Tundra Access Cab	C810-BRK-42	C110-CU70	C310-CU70	C410-CU70	C610-CU70	C810-CU70
04-06	Tundra D-Cab (Unlighted boards Only)	C810-BRK-43	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-15	Tundra Standard Cab	C810-BRK-145S	C110-CU54	N/A	C410-CU54	C610-CU54	C810-CU54
07-15	Tundra D-Cab	C810-BRK-145	C110-CU80	C310-CU80	C410-CU80	C610-CU80	C810-CU80
07-15	Tundra Crew Max	C810-BRK-145	C110-CU90	C310-CU90	C410-CU90	C610-CU90	C810-CU90