

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
ACURA							
MDX	SUV	2001-07	4058	3965	4059	Clamp-On	4060
SLX w/o sunroof	SUV	1996-99	4058	4255	4059	Clamp-On	3948
RDX	SUV	2007					
BUICK							
Terazza	mV	2005-07	4468	4575	4479‡	MB3747	4460
CADILLAC							
SRX	SUV	2004-07	4578	4575	4779	MB3747	
CHEVROLET / GMC							
Aveo	W	2004-07	3448‡	3445‡	3449‡		
HHR	W	2006-07	3968	3965	3969		3948
Malibu Maxx	W	2004-06	n/a	n/a	n/a	n/a	n/a
Astro / Safari	mV	1986-98	4768‡	4765*	4669‡	MB3762	4872
Astro / Safari (LWB)	mV	1986-04	4778*	4775‡	4679*	MB3762	4872
Express / Savana	V	1996-07	5178*	5072‡	5179	-	5172
Sportvan / Vandura	V	1986-95	4778*	4775‡	4679‡	-	5172
Uplander	mV	2005-07	4578	4575	4479‡	MB3747	4460
Venture (SWB)	mV	1997-04	4568	4565	4459‡	MB3747	4460
Venture (LWB)	mV	1997-05	4578	4575	4469	MB3747	4472
Equinox	SUV	2005-07	3968	3865‡	3759‡	-	
S-Blazer / Jimmy 2dr	SUV	1986-05	4258	4255	4049	Clamp-On	3948
S-Blazer / Jimmy 4dr	SUV	1990-05	4258	4255	4059	MB3747	4060
Suburban	SUV	1992-99	5178*	5175	5179	MB3762	5172
Suburban / Yukon XL	SUV	2000-07	4988‡	4985	4879	MB3762- 2	4872
Tahoe / Yukon 2dr	SUV	1992-99	5168‡	5165*	5159‡	MB3762	5172
Tahoe / Yukon 4dr	SUV	1995-99	5178*	5175‡	5179‡	MB3762	5172
Tahoe / Yukon 4dr	SUV	2000-07	4978	4975	4869‡	MB3762- 2	4872
Tracker 4-dr	SUV	1999-03	3648	3645*	3659‡	MB3747	3648
Trailblazer/Envoy [swb]	SUV	2002-07	4368*	4365	4459	-	4460
Avalanche	SUT	2002-07	4958	4955	4849‡	MB3762- 2	4460‡
Colorado/Canyon CrewCab	PU	2004-07	3648	3645	3749	MB3747	3648
Silverado/Sierra CrewCab	PU	2001-07	4948‡	4945	4849‡	-	
S-Series CrewCab	PU	2001-04	4348‡	4345‡	4449‡	MB3747	4460‡
CHRYLSE - DODGE - PLYMOUTH							
Caliber	W	2007	4048	4045	4049		-
Magnum	W	2005-07	4258	4355‡	4359‡	MB3747	4460‡
Pacifica	W	2004-07	3968	3965	4069‡	-	4460
PT Cruiser	W	2000-07	3648		3649	OE Track	3648
Caravan / Voyager (SWB)	mV	1984-95	4768‡	4765*	4469	Clamp-On	4460
Caravan / Voyager (SWB)	mV	1996-00	4568	4565	4469	MB3747- 2	4460
Caravan / T&C/Voyager (SWB)	mV	2001-07	4568	4565	3969‡	MB3747- 2	4460‡
Grd.Caravan / Town&Country	mV	1990-95	4768‡	4765*	4469	Clamp-On	4472
Grd.Caravan / Town&Country	mV	1996-00	4568	4575	4479*	MB3747- 2	4472
Grd.Caravan / Town&Country	mV	2001-07	4568	4575	3979‡	MB3747- 2	4472‡
Ram Van / Wagon	V	1998-02	5368	5365*	5359*	-	-
Sprinter	V	2003-07				-	
Aspen	SUV	2007	4068‡	4065	4069	MB3747	
Durango	SUV	1999-03	3958‡	3955‡	4059	-	3948
Durango	SUV	2004-07	4068‡	4065	4069	MB3747	
Ramcharger	SUV	1974-95	4558‡	4555‡	4459‡	-	4872
Dakota QuadCab	PU	2001-07	4548‡	4345‡	4449‡	OE Track	4460‡
Ram QuadCab	PU	2000-07	4548‡	4545‡	4639‡	-	4460‡
Ram MegaCab	PU	2006-07	4558	4555	4459	-	4460

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
4058*	4060	4055	
4058*	4060	4055‡	
4478*	4470	4462	-
100% OE INSTALL			
	3450‡		
n/a	n/a	n/a	n/a
4772*	4770	-	4874
4778*	4780‡	-	4874
5088*	5080	-	4874
4778*	5080‡	-	4874
4478*	4470	4462	-
4466*	4460	4462	-
4478*	4470	4462	-
4053*	4050	4055	
4058*	4060	4055	
5088*	5080	-	4874
5088*	5080	-	4874
5058*	5060‡	-	4859*
5072*	5070‡	-	4859*
5072*	5070‡	-	4874
3648*	3650	4055‡	-
4466*	4460	4462	-
5053*	5050‡	-	-
3648*	3650	4055‡	
-	4850‡		
4448*	4450‡	4055	4459
-	-	4462‡	
4072*	4070	4462‡	4459
-	3650	4055‡	-
4466BE*	4470	4462	4459
4466*	4470	-	
-	3970‡	-	
4466*	4470	4462	4474*
4466*	4470	-	
-	3980‡	-	
5364*	5360*	-	-
4058*	4060	-	-
	4470	4462	
[4453*]	[4460]		[4459]
4442*	4440‡	-	-
	4440‡		

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
FORD							
Edge	W	2007					
Escort	W	1991-99	3648	3645	3439 ‡	-	3648†
Focus	W	2000-07	3658	3665	3669‡	MB3747	3660
Econoline / Club Wagon	V	1992-07	4778*	4775*	4869*	-	4872
Freestar	mV	2004-07	4068*	3665	4069	SQ CM	4060†
Windstar	mV	1995-03	3658‡	3655	4059	OE Track	3648
Escape	SUV	2001-06	4258	4255	4049	OE Track	3648
Expedition	SUV	1997-07	4568	4365	4469	OE Track	4460
Expedition EL	SUV	2007					
Explorer (2 & 4 dr)	SUV	1990-01	4258	4255*	4059	OE Track	4060
Explorer w/ sunroof	SUV	1990-01	-	-	4049	OE Track	-
Explorer 4dr	SUV	2002-04	4058	4255	4059	MB3747	4060
Explorer 4dr	SUV	2005-06	4058	4255	4059	SQ55CM-B	4060
Explorer Sport 2-dr	SUV	2001-05	4258	4255	4059	MB3747	4060
Explorer SportTrac	SUT	2001-06	4238	4245	4039	MB3747	-
Explorer SportTrac	SUT	2007					
F150 SuperCrew [Heritage]	SUT	2000-03	4348‡	4345‡	4449*	-	4460†
F150 SuperCrew	SUT	2004-07	4948‡	4945‡	4849	-	4872†
SuperDuty F250/350 CrewCab	PU	2000-06	4548	4545*‡	4449*	-	4460†
Ranger CrewCab	PU	2001-07	4548	4548	4449*	OE Track	
HONDA							
Accord	W	1990-97	3448*	3445*	3449‡	OE Track	3248
Fit	H	2007					
Odyssey	mV	1995-99	3658*	3655‡	3649‡	Clamp-On	3660 †
Odyssey	mV	2000-04	3758	3755‡	3759‡	MB3747	3660
Odyssey	mV	2005-07	4068 ‡	4065‡	4069	MB3747	
CR-V	SUV	1997-01	3758	3755	3649	MB3747	3648
CR-V [integral OE Rails]	SUV	2002-06	n/a	n/a	n/a	n/a	n/a
CR-V	SUV	2007					
Element	SUV	2003-07	4258	4255	4059	-	4060
Passport	SUV	1994-97	3648	4255	4039 ‡	OE Track	-
Passport	SUV	1998-02	3648	3755‡	3649	MB3747	3648
Pilot	SUV	2003-07	4158 ‡	4065‡	4059	MB3747	4060
Ridgeline	SUT	2005-07	4548 ‡	4545‡	4649‡	-	4460
HUMMER							
H3	SUV	2006	4068	4075*	4069	OE Track	
HYUNDAI							
Entourage	mV	2007					
Santa Fe	SUV	2001-06	3658	3865	3759‡	MB3747	3660
Santa Fe	SUV	2007					3660
Tucson	SUV	2005-07	3958 ‡	3955‡	3759‡	MB3747	
INFINITI							
FX35 / FX45	SUV	2004-06	-	3445	3649	MB3747	
ISUZU							
Axxiom	SUV	2002-05	3668	3655	3649	-	3648
Rodeo	SUV	1992-97	3648	4255	4039 ‡	SQ-Jeep*	-
Rodeo	SUV	1998-04	3758	3755‡	3649	MB3747	3948
Trooper	SUV	2001-03	3958‡	3955‡	4059	Clamp-On	3948
I-Series CrewCab	PU	2006-07	3648	3645	3749	MB3747	3648

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
PERRYCRAFT			
Contempo*	TracMate	Winmaster	Premium
FORD			
3542*	3540‡	4055†	
-	3670‡	4462†	-
4778*	4780*	-	4874†
4058*	4070		
4058*	4060	4055	
4053*	4050	4055	-
4466*	4470	4462	4459
4058*	4060	4055	3959*
4053*	4050	-	-
4058*	4060	4055	3959*
	4060		
4058*	4060	4055	3959*
-	4040	-	-
4448*	4450‡	4462†	4459†
	4850		
4448*	4450‡	4462†	4459†
HONDA			
3448‡*	3450‡	4055 †	
3648*	3650	4055 †	-
3658‡*	3660	4055†	
-	4070		
3648‡*	3650‡	4055 †	-
n/a	n/a	n/a	n/a
4058*	4060	4462†	
4044*	4040‡	4055†	3944-3*
3648‡*	3650	4055†	-
4058*	4060	4055	-
4448*	4450‡	4462 †	
HUMMER			
-	4070		
HYUNDAI			
3658‡*	3660‡	4055†	-
-	3660‡		
INFINITI			
ISUZU			
3648	3650	4055†	-
4044*	4040‡	4055†	3944-3*
3648*	3650	4055 †	-
4058*	4060	4055	-
3648*	3650	4055†	

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
JEEP							
Compass	W	2007					
Cherokee, Cherokee Sport	SUV	1984-01	4368*	4365‡	4469	SQ-Jeep*	-
Commander	SUV	2006-07	4568	4365	4459	-	-
Grand Cherokee	SUV	1992-98	3658*	3655	4059	Clamp-On	4060
Grand Cherokee	SUV	1999-04	3658*	3655	4059	MB3747	-
Grand Cherokee	SUV	2005-07	4558‡	4555‡	4459	MB3747	-
Liberty [cut for tapered fit]	SUV	2002-07	3958‡	3955‡	3759‡	MB3747	4039*
Patriot	SUV	2007					
Wrangler Sport [Hard Top]	SUV	2007	[4758]	[4755]	-	-	-
Wrangler Unlimited [Hard Top]	SUV	2007	[4558]	[4555]	-	-	-
KIA							
Rio Cinco	W	2002-05	3648	3645‡	3745‡	-	-
Rio5	W	2006-07				-	-
Spectra5	W	2005-07	3648	3655‡	3749	-	-
Sedona	mV	2002-05	4078	3975	4069‡	MB3747	4060†
Sedona	mV	2006-07	4078	3975	4069‡	MB3747	4472‡
Sorento	SUV	2003-06	3868‡	3865	3759‡	MB3747	3948
Sorento	SUV	2007					
Sportage	SUV	1995-03	3648	3645	3649	SQ-J* / 3747	3948
Sportage	SUV	2005-06	3958‡	3955	3749	MB3747	4060†
MAZDA							
Mazda3	H	2004-07	3638	3645	3739‡	-	3648†
Mazda6 [cut for tapered fit]	W	2004-07	3658‡	3655	3649	MB3747	3648
Mazda5	W	2006-07	3658	3655	3759	-	-
MPV	mV	1989-99		3955‡	4059	OE Track	3948
MPV	mV	2000-03	3668‡	3665	3649	MB3747	3648
MPV	mV	2004-05	3568‡	3565‡		MB3747	3648
CX-7	SUV	2007					
CX-9	SUV	2007					
Tribute	SUV	2001-07	4--58	4255	4049	Clamp-On	3648
MERCURY - LINCOLN							
Monterey	mV	2004-05	3668	3665	4069	MB3747	4060†
Villager	mV	1993-02	4058	3955‡	4059	OE Track	4060
Mariner	SUV	2005-06	4058	3955‡	4059	MB3747	
Mark LT	SUT	2006	4948‡	4945‡	4839	-	4872‡
MINI							
Cooper [without sunroof]	W	2002-06	3648	3645	3649	special MB	3648
MITSUBISHI							
Lancer Sportback	W	2004-06	3658‡	3765‡	3759‡	MB3747	3660
Endeavor	SUV	2004-06	4048‡	4045‡	4049	Clamp-On	3948
Montero (full-size)	SUV	2001-04	4368‡	4365	4069‡	MB3762	4060
Montero Sport	SUV	1997-00	3658‡	3655	3759‡	OE Track	3648
Montero Sport [rails or tracks]	SUV	2001-04	3658‡	3655	3759‡	OE-T / 3747	3648
Outlander	SUV	2003-06	3558‡	3455‡	3459‡	MB3747	3648
Outlander	SUV	2007					

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
PERRYCRAFT			
Contempo*	TracMate	Winmaster	Premium
4466*	4470	-	4874
4058*	4060	4462	
4058*	4060	4055	4874
-	4460	4462	-
4058*	3660‡	4055†	-
PERRYCRAFT			
3636*	3640	4055†	
4066*	4070	4462†	-
-	3660‡	4462†	
3648*	3650	4055†	4248-9*
-	-	4055	
PERRYCRAFT			
3636*	3640	4055†	
3648*	3650	4055†	
4053*	4060	4055†	4859
3648*	3650	4055†	-
3572*	3570‡		
PERRYCRAFT			
4053*	4050	4055†	
PERRYCRAFT			
4058	4060	4055†	3944-3*
4058	4060	4055	
	4850		
PERRYCRAFT			
	3650	4055†	
PERRYCRAFT			
-	3660	4055†	
4048*	4050	4055†	-
4072*	4070‡	4462†	3959*
3858‡*	3860‡	4055†	3959*†
3858‡*	3860‡	4055†	3959*†
3458‡*	3460‡	3655†	-

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
NISSAN							
Quest	mV	1993-98	3958‡	3955‡	4059	OE Track	4060
Quest	mV	1999-03	3958‡	3955‡	4059	OE Track	4060
Quest	mV	2004-07	4368‡	4365‡	4459	MB3747	4460
Armada	SUV	2004-07	4558‡	4555‡	4459	-	4460
Murano	SUV	2003-07	4058‡	3955‡	4049	MB3747	4060†
Pathfinder	SUV	1989-95	3948‡	3945‡	4049	OE Track	3948
Pathfinder	SUV	1996-02	3448‡	3445‡	3459‡	OE Track	3648
Pathfinder	SUV	2003-04	3448‡	3445‡	3459‡	-	4060
Pathfinder	SUV	2005-07	4068‡	4065‡	4069	Clamp-On	4060
Frontier CrewCab	PU	1998-04	4048‡	4045‡	4049‡	-	3948
Frontier CrewCab	PU	2005-07	4348‡	4345‡	4049‡	-	3948
Titan CrewCab	PU	2004-07	4558‡	4555‡	4849‡	-	-
PONTIAC							
Montana SV6	mV	2005-07	4578	4575	4479	MB3747	
TransSport APV	mV	1989-96	[4458‡]	[4455‡]	[4459]	OE Track	-
TransSport/Montana (LWB)	mV	1997-04	4578	4575	4469	MB3747	4472
Torrent	SUV	2006-07				-	
SATURN							
Relay	mV	2005-06	4578	4575	4479‡	MB3747	4460
Outlook	SUV	2007					
Vue	SUV	2002-06	3958‡	3955‡	4059	-	4060
SCION							
xA	H	2004-06	3348‡	3345‡	3349‡	-	
xB	SUV	2004-06	4368‡	4365‡	4469	-	4460
SUBARU							
B9 Tribeca	SUV	2006-07	3958	3955	4059		4460
Forrester	SUV	1998-07	3648	3645	3449‡	-	3648
SUZUKI							
Aerio SX	W	2003-05	3448‡	3445‡	3449‡	-	3248
Grand Vitara, Vitara	SUV	1998-05	3648	3645	3649‡	MB3747	3648
Grand Vitara	SUV	2006-07	3658	3655		MB3747	
SX4	SUV	2007					
XL-7	SUV	2001-06	3648	3645	3649‡	MB3747	3660†
XL7	SUV	2007					
TOYOTA							
Matrix [w/o sunroof]	W	2003-07	3648	3645	3649	-	3648
Yaris	H	2007					
Sienna	mV	1998-03	4258	4255	4059	MB3747	4060
Sienna	mV	2004-07	4578	4575	4469	MB3747	4460
4-Runner	SUV	1989-95		3645	3649	OE Track	3648
4-Runner [OE = GSB30-7023]	SUV	1996-02	3648	3645	3649	OE Track	3648
4-Runner	SUV	2003-07	3958	3965	4069	MB3747	4472†
Highlander	SUV	2002-07	3978‡	3975	3779‡	MB3762	4472†
RAV4 4-dr	SUV	1996-00	3648	3645	3449‡	-	3248
RAV4 [no sunroof / with sunroof]	SUV	2001-05	3658 / 48	3655 / 45	3449‡	MB3747	3660 / 48
RAV4	SUV	2006-07	3968	3965	-		
Sequoia	SUV	2001-07	4578	4575	4679‡	MB3762	4472
Tacoma DblCab	PU	2001-04	3648	3645	3649‡	MB3747	3948†
Tacoma DblCab	PU	2005-07	4048‡	4045‡	4049	-	3948
Tundra DblCab	PU	2004-06	4548‡	4545‡	4439‡	-	-
Tundra DblCab	PU	2007					

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
4058*	4060	4055	3944-3*
4058*	4060	4055†	3944-3*
-	4460	4462	
-	4460	4462†	-
4053*	4050	4055	-
4048*	4050	4055†	3944-3*
3458‡*	3460‡	4055†	-
3458‡*	3460‡	4055†	-
-	4070	4055†	-
4048*	4040‡	4055†	
-	4040‡	4055†	
-	4850‡		
4479‡*	4480‡	4462	
[4453*]	[4460]	-	-
4466*	4470	4462	-
4478*	4470	4462	-
4053*	4060	4055	
	3350‡		
	4470	4462	4459
3648*	4060		
	3650	4055†	-
3342‡*	3450‡	4055†	
3648*	3650	4055†	-
3648*	3650	4055†	-
3648*	3650	4055†	-
3648*	3650	4055†	-
4058*	4060	4055	3959*
4472*	4470	4462	
3648	3650	4055†	3959*†
3648*	3650	4055†	3959*†
4066*	4070	4462†	-
3678‡*	3680‡	4055†	-
3648*	3650	-	-
3648*	3650	4055†	-
4478*	4480‡	4462	4474*
3542*	3640‡	4055†	
-	4050		
-	4440‡		

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa

LEGEND * Non Stock - SPO +1 or +2 = # add'l slats required [ROOFAPPS.xls 7/19/06](#)
 † May need to cut rack L or W to fit [] Use FG mount kit or bolt thru (no clearance to headliner)
 ‡ use larger [stock] size rack and cut to size shown SWB / LWB: Short/Long wheelbase
 H=Hatchback W=Stn Wagon V=Van mV=miniVan SUT/PU=Truck SUV=Sport-Utility Vehicle Sizes: Width x Length
BOLD indicates OE styling SportQuest/MontBlanc Upgrade indicates style to use with OE rack

PERRYCRAFT	RackMaster	DYCREST
Contempo*	TracMate	Winmaster
		Premium

----- Out of Print Roof Rack Applications - July 2006 -----							
ACURA							
MDX	SUV	2008					
AUDI							
A3 Sportback	W	2006-07				Clamp-On	
A4	W	1999-04	100% OE INSTALL Roof Rails			Clamp-On	
A6 Avant	W	1999-07	100% OE INSTALL Roof Rails			MB3747	
Q7	SUV	2007	100% OE INSTALL Roof Rails			Clamp-On	
BMW							
5, 6, 7 Series	W	97-06	100% OE INSTALL Roof Rails			MB3747	
X3	SUV	2004-06	100% OE INSTALL Roof Rails			MB3747	
X5	SUV	2000-06	100% OE INSTALL Roof Rails			MB3747	
BUICK							
Estate Wagon	W	1980-87		4255*	4059	Clamp-On	4060
Century	W	1984-96		4045‡	4049	Clamp-On	
Roadmaster	W	1992-95		4045‡	4069	OE Track	
Rainier [Tblzr rack]	SUV	2004-05	100% OE INSTALL			-	
Rainier [silver roof rails]	SUV	2006-07	100% OE INSTALL			MB3747	
Rendezvous	SUV	2002-06	100% OE INSTALL			OE Track	
CADILLAC							
Escalade	SUV	1999-01	100% OE INSTALL				
Escalade	SUV	2002-06	100% OE INSTALL				
Escalade ESV	SUV	2003-07	100% OE INSTALL				
Escalade EXT	SUT	2003-07	100% OE INSTALL				
CHEVROLET / GMC / GEO							
Storm (wagon-back)	W	1991-92					
Metro	H	1990-94					
Metro	H	1995-96					
Prizm, Spectrum	H	1988-92					
Caprice	W	1984-91					
Caprice	W	1992-96			4069‡		
Cavalier	W	1982-94		3645	3649	Clamp-On	
Celebrity	W	1983-91			4059	Clamp-On	
Lumina APV	mV	1989-96		[4459*]	[4459]	OE Track	
Denali	SUV	1998-01	100% OE INSTALL			Clamp-On	
K Blazer [fiberglass roof]	SUV	1969-91			[4449*]		
Suburban	SUV	1973-91		4775*	4679*	MB3762	4872
Tracker 4-dr [GEO]	SUV	1995-98		3645	3649	MB3747	3648
Trailblazer EXT/Envoy XL	SUV	2003-07	100% OE INSTALL				
CHRYLSE - DODGE - PLYMOUTH							
Aries/Reliant - K	W	1986-90					
Omni/Horizon	H	1986-91				OE Track	
Colt Vista	W	1986-91					
Colt Vista	mV	1992-93			3649		
Ram Van / Wagon	V	1986-98		5375*	5179	-	5172
Raider	SUV	1988-91					
DAEWOO Nubria	W	1999-02				Clamp-On	
FORD							
Escort	W	1986-90				OE Track	3648†
Festiva	H	1984-93					

Out of Print Roof Rack Apps - July 2006			
100% OE INSTALL Roof Rails			
100% OE INSTALL Roof Rails			
100% OE INSTALL Roof Rails			
100% OE INSTALL Roof Rails			
100% OE INSTALL Roof Rails			
100% OE INSTALL Roof Rails			
4466*	4460		4459
4053*	4050	4055	3959*
4066*	4070	4055	3959*
100% OE INSTALL			
100% OE INSTALL			
100% OE INSTALL			
100% OE INSTALL			
100% OE INSTALL			
3336*	3340*		-
3636*	3640* †		-
n/a	n/a	n/a	n/a
3636*	3635* †		-
4466*	4460		4459
4066*	4070		4459
3648*	3650		
4053*	4050		3944
[4453*]	[4460]	-	n/a
100% OE INSTALL			
[4453*]	[4450*]	-	-
4772	4770	-	4874
3648*	3650	4055†	-
100% OE INSTALL			
4053*	4050	4055†	3944
3648*	3840*		
3853*	3850*		
3853*†	3850* †	4055†	
5372*	5380	-	4874†
3636*	-		-
100% OE INSTALL			
3648*	3650		
3542*	3540		-

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
Focus 3/5 dr Hatch	H	2000-07	3668	3665	3669		
LTD Country Squire	W	1982-91					
Taurus	W	1986-95				4059	OE Track
Taurus	W	1996-99		100% OE INSTALL			OE Track
Taurus	W	2000-05	100% OE INSTALL			OE Track	
Aerostar	mV	1986-98		4565	4469	OE Track	4460
Econoline	V	1975-91		4775*	5179†	-	5172†
Bronco II	SUV	1985-90		4255†	4049	OE Track	4060
Bronco (full size, fiberglass top)	SUV	1980-96		4545‡	4449	-	
Excursion	SUV	2000-06	100% OE INSTALL			OE Track	
Freestyle	SUV	2005-06	100% OE INSTALL			MB3747	
HONDA							
Civic	W	1980-91					
Civic	H	1992-00		3445*	3439‡	-	
Civic	H	2002-05					
HYUNDAI							
Elantra	W	1996-97		3445*	3449‡		
HUMMER							
H2	SUV	2003-06	100% OE INSTALL				
H2	SUV	2005-06	100% OE INSTALL				
INFINITI							
QX4	SUV	1997-00	100% OE INSTALL			OE Track	
QX4	SUV	2001-03	100% OE INSTALL			OE Track	
QX56	SUV	2004-06					
ISUZU							
Oasis	mV	1995-99		3655‡	3649‡	-	3660†
Ascender 5p (SWB)	SUV	2004-05	100% OE INSTALL			OE Track	
Amigo/Rodeo Sport	SUV	1999-01					
Ascender [lwb]	SUV	2003-06					
Trooper II - 2 dr	SUV	1984-91		-	-	-	
Trooper II - 4 dr	SUV	1984-91		-	4869*	OE Track	
Trooper (w/o sunroof)	SUV	1992-00		3955‡	4059	Clamp-On	3948
JEEP - EAGLE							
Summit	mV	1992-95					
Grand Wagoneer (full size)	SUV	1963-91					
Wrangler [FG hard top]	SUV	1996-06					
Wrangler Unlim. [FG hard top]	SUV	2005-06					
LAND ROVER							
Discovery	SUV	1995-98				MB3762	
Discovery II	SUV	1999-04				MB2763	
LR2	SUV	2007					
LR3	SUV	2005-07					
Freelander	SUV	2003-04				MB3747	
Range Rover Classic	SUV	1989-95					
Range Rover	SUV	1995-02					
Range Rover	SUV	2003-06	4258	4355	4359		
Range Rover Sport	SUV	2006-07					
LEXUS							
GX470	SUV	2003-06					
LX450	SUV	1996-97	100% OE INSTALL			Clamp-On	
LX470	SUV	1998½-03	100% OE INSTALL			MB3747	
RX300	SUV	1998-03	100% OE INSTALL			OE Track	
RX330	SUV	2004-06		3855	3759‡	MB3747	
MAZDA							
323	H, W	1986-92					
Protégé 5	W	2000-03		3355	3349	OE Track	3248

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
4466*	4460		
4053, 4058*	4060	4055	-
100% OE INSTALL			
100% OE INSTALL			
4466*	4470	4462	4459
5372*	5380	-	4874
4053*	4050	4055	3959*
[4448*]	[4450‡]	-	-
100% OE INSTALL			
100% OE INSTALL			
3636†*	3640* ‡		-
3336*	3340‡	4055†	
3648	3650	4055†	
100% OE INSTALL			
100% OE INSTALL			
3648	3650	4055†	-
100% OE INSTALL			
4036*	4040‡	-	-
4772	4770	4055	-
4058*	4060	4055	3959*†
3853‡	3850‡	4055†	
4466	4460		4459
5358*	5360* †	5262	
4358	4360	4462†	
100% OE INSTALL			
100% OE INSTALL			
100% OE INSTALL			
4058	4060		
3436*	3440* †		-
3353	3350	4055†	

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
Navajo	SUV	1990-94		4255	4059	-	4060
MERCEDES							
300	W	1986-94					
E320	W	1997-03				MB3747	
C-Series	W	2000-04					
R-Class GST	W	2006					
G320 Geländewagon	SUV	1997-06					
M-Class	SUV	1998-07		3955	4059	MB3747	4060
MERCURY - LINCOLN							
Grand Marquis	W	1984-91			4459		
Sable	W	1985-95					
Sable	W	1996-04					
Tracer	W	1991-99		3645	3439‡	OE Track	
Aviator	SUV	2003-05				MB3747	
MKK	SUV	2007					
Mountaineer	SUV	1996-01		4255*	4059	MB3747	
Mountaineer	SUV	2002-04				MB3747	
Navigator	SUV	1997-07				MB3747	
Navigator L	SUV	2004					
Blackwood	SUT	2002					
MITSUBISHI							
Diamante'	W	1993-96		3655*	3759‡		
Expo	W	1992-95		3955‡		OE Track	
Expo LRV	mV	1992-95		3655*	3649‡	Clamp-On	
Van	mV	1989-91			4459		
Montero - 4 dr w/ sunroof	SUV	1992-99		3955‡	4359‡	MB2763	3948
Montero - 4 dr w/o sunroof	SUV	1992-99		3955‡	4359‡	MB2763	4060
NISSAN							
Maxima	W	1988-95		-	3739‡	-	3648
Sentra	W	1988-90					
Stanza	W	1988-90					
Van	mV	1989-92					
Xterra	SUV	2000-04				Clamp-On	
Xterra	SUV	2005-07				Clamp-On	
OLDSMOBILE							
Custom Cruiser	W	1983-90					
Cutlass Cruiser	W	1991-95					
Silhouette APV	mV	1990-96		[4459*]	[4459]	OE Track	-
Silhouette (LWB)	mV	1997-03		4565	4469	MB3747	4472
Bravada	SUV	1991-94		4255	4059	OE Track	4060
Bravada	SUV	1996-00	100% OE INSTALL			Clamp-On	
Bravada	SUV	2002-03		4365	4459	OE Track	4460
PONTIAC							
6000 L/E	W	1982-90					4060
Le Mans	H	1989-93					
Parisienne	W	1984-91					
Vibe	W	2003-06	100% OE INSTALL			Clamp-On	-
Aztek	SUV	2000-06	100% OE INSTALL			OE Track	
SATURN							
LW (L series wagon)	W	2000-06	3668‡	3665	3669‡	MB2743	3660
SW (S series wagon)	W	1992-02		3645*	3449‡	MB2743	3248
SAAB							
9-5 SportWagon	W	2003-06				MB	
9-7X	SUV	2005-06				Clamp-On	
SUBARU							
Imprezza	W	1993-02	3338‡	3335‡	3339‡	-	

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
4058	4060	4055	3959*
100% OE INSTALL Roof Rails			
4072* †	4070†		-
100% OE INSTALL Roof Rails			
4058	4060	4055†	
100% OE INSTALL			
4466	4460		-
4053, 4058	4060	4055	3959*
100% OE INSTALL			
3542*	3540‡	4055†	
100% OE INSTALL			
4058	4060	100% OE INSTALL	
100% OE INSTALL			
100% OE INSTALL			
100% OE INSTALL			
3648*	3650	3755†	
4053	-	4055	
3648*	3650* †	3755†	
4466	4460		
4358*	4360‡	4055	-
4358*	4360‡	4055†	3959*
100% OE INSTALL			
3842*	3840* †	4055†	-
-	3840†		-
-	3842†		-
4466	4460		4459
100% OE INSTALL			
4466	4460		3959*
4053	4050	4055	3959*
[4453]	[4460]	-	-
4466	4470	4462	4559-8
4058	4060	4055	3959*+1
100% OE INSTALL			
4466	4460	4462	
100% OE INSTALL			
4053	4050		3959*
3636*	3635*		-
4466	4460		-
100% OE INSTALL			
100% OE INSTALL			
3672*	3670‡	4462†	-
3648*	3650‡	4055†	
100% OE INSTALL			
100% OE INSTALL			
3342‡*	3340 ‡	-	-

DONMAR Roof Rack Applications

VEHICLE Make, Model	Body Style	YEARS From-To	PERRYCRAFT			SQ / MB	DYCREST
			Aventura	DynaSport	SporTrek	OE Upgrade	Activa
Imprezza	W	2003-06	100% OE INSTALL			MB2743	
Justy	H	1986-94					
Legacy	W	1990-94			3649		
Legacy	W	1995-97		3045‡	3649	-	-
Legacy	W	1998-02	4148‡	4145‡	3949*	MB2743	-
Loyale	W	1990-94			3649	-	
Outback [Imprezza]	W	2001-04	100% OE INSTALL			MB2743	
Outback [Legacy]	W	1996-02	100% OE INSTALL			MB2743	
Baja	SUT	2003-05				OE Track	
SUZUKI							
Esteem	W	1999-02					
Forenza	W	2005-06	100% OE INSTALL Roof Rails				
Swift	H	1990-94					
Swift	H	1995-96		[3645]	[3449‡]		
Samurai (hard top)	SUV	1984-94					
Sidekick	SUV	1989-97		3755‡	3649	Clamp-On	3648
TOYOTA							
Camry	W	1986-92					
Camry	W	1993-96		3459‡	3459‡	Clamp-On	3648‡
Corolla	W	1990-92			3649	OE Track	
Corolla	W	1993-96		-	3649	OE Track	3248
Cressida	W	1988-92			4059		
Tercel	W	1988-92					
Previa [w/o sunroof]	mV	1991-97		4365*	4059	Clamp-On	4060
Land Cruiser	SUV	1978-90		-	-	-	4460
Land Cruiser	SUV	1991-98		4355*	4459	Clamp-On	4060
Land Cruiser	SUV	1998½-06	100% OE INSTALL			Clamp-On	
RAV4 2-dr	SUV	1996-00		3645	3449‡		
VOLKSWAGON							
Golf	H	1987-06		3435*	3439*	-	
Jetta	W	2002-06		-	-	MB2743	
Passat	W	1991-06		-	3359‡	MB2743	3248
Passat	W	2007					
Quantum	W	1988-92					
Rabbit	H	1981-88					
Rabbit	H	2007					
Eurovan	mV	1993-96					
Eurovan	mV	1999-03					
Van	nM	2008					
Vanagon	mV	1978-92			4669*		
Vanagon	mV	1993-94					
Toureg	SUV	2003-07					
VOLVO							
240	W	1975-93		4355*	4459	Clamp-On	4060
740, 760	W	1986-96		4355*	4459	Clamp-On	4060
850, 940, 960	W	1994-96		3955‡	4059	Clamp-On	4060
V40, V50	W	2000-06		3655	3649	MB2743	3648
V70	W	2001-06		3655	4059	Clamp-On	4060
XC90	SUV	2003-06		3965	4469		4460

PERRYCRAFT		RackMaster	DYCREST
Contempo*	TracMate	Winmaster	Premium
100% OE INSTALL			
3636	3630*		-
3648	3650	4055‡	
3648	3650	4055‡	3944-3*
4048*	4050	4055‡	3944-3*
3648	3650	4055‡	
100% OE INSTALL			
100% OE INSTALL			
		4055‡	-
3636*	3540‡		-
n/a	n/a	n/a	n/a
[3648]	-		-
3648	3650	4055‡	-
3648	3650		-
3558*	3560 ‡	4055‡	-
3648‡	4050‡		
3648	3650	-	
4053	4050	4055‡	3944
3648	-		-
4058	4060	4055	-
4453*	4460	-	4459
4453*	4460	4462‡	3959*
100% OE INSTALL			
3648	3650		-
3436* ‡	3440* ‡	-	-
-	-	-	
3353* †	3360‡	-	
-	3840‡		-
3636	4050‡ ‡		-
4053	-	4055	-
4778* †	4770		-
4053	-		-
4453*	4450* ‡	4055	3959*
4466	4460	4055	3959*
4058	4060	4055	3959*
3648	3650	4055‡	
4058	4060	4055	
4066	4470	4462	