

INSTALL INSTRUCTIONS: TTA-312A Fog Light Kit 2012 Toyota Tacoma (Universal Wiring Harness)



KIT CONTENTS: LH & RH lamp; Wire Harness w/ Relay; Switch

1. Disconnect the positive terminal of the battery
2. Remove filler plugs from bezels in front bumper
3. Mount lamps into bezels
4. Wire BLACK wire to floating negative (body ground)
5. Connect WHITE wire to 10A switched accessory positive at fuse block
6. Connect RED signal wire to low beam harness, positive lead for signal with a T-Tap
7. Connect H11 sockets to bulbs in lamp assemblies
8. Connect green socket to dash switch
9. Mount switch in factory knockout to left of steering wheel
10. Re-connect battery terminal
11. Test fog lights



TTA-312A 2012 Tacoma Fog Light Kit

DONMAR[®]
SUNROOFS & ACCESSORIES

www.donmar.com