

# TECHNICAL SERVICE BULLETIN

## Nissan Titan Full Sized Truck & Armada SUV Overhead Console Modification for inbuilt sunroof installation



1. Remove front console from vehicle.
2. Mark cut line along edge of flip door as shown
3. Cut straight across marked line
4. Discard rear section with 3 flip doors.



5. Mark and cut sides of console to wrap around leading edge of sunroof pan.
6. Trim and sand cut edges smooth.
7. Install sunroof.
8. Re-mount front and back (DVD) consoles.



Titan/Armada Front



Titan Rear (DVD)



Armada Rear (DVD)

**DONMAR**  
**SUNROOFS & ACCESSORIES**

1-800-SUNROOF

904/731-3393 · fax 904/731-0004

<http://www.donmar.com>