

Mirror Mount Reference Guide

WEDGE/D-TAB MOUNT



Fits Brandmotion mirrors
Used on most vehicles

CAMLOCK MOUNT



Fits Brandmotion mirrors with adaptor
P/N: 5000-Camlock
Used on some Honda models

TRI-LOBE/TWIST OFF MOUNT



Fits Brandmotion mirror
P/N: 9002-9618
Used on some Ford, Dodge, Chrysler, BMW, Jaguar models

HYUNDAI MOUNT



No direct adaptor currently available
Professionally remove existing mount and replace with P/N: 9002-6112 D-Tab Mounting Kit to fit Brandmotion mirrors
Used on some Hyundai models

VW/AUDI MOUNT



Fits Brandmotion Mirrors with Adaptor
P/N: 5000-VWAB
or
P/N: 5000-VWAB2
Used on some VW/Audi models

SPRINTER/SMART MOUNT



Fits Brandmotion mirrors with adaptor
P/N: 5000-SPRNTAB
Used on Sprinter, Smart, and some Hyundai models