# **DONMAR Seat Heater Options**





## **DONMAR Seating Comfort Options**



#### LA200-9447 Manual Pneumatic Lumbar

- ergonomic butterfly shape
- durable poleyethylene bladder
- mounts between foam and seat skin
- squeeze bulb with quick release valve

## L-AC003LB Power Pneumatic Lumbar

- ergonomic butterfly shape
- durable plasticized cloth bladder
- front or rear mount
- round switch with icon

L181-63-L Manual 2-way Mechanical Lumbar

- rugged rear mount metal spring frame
- infinite adjustment up to 1.4" displacement
- models for driver or passenger seat

L315-0682 Power 2-way Mechanical Lumbar

- rugged rear mount hybrid spring frame
- infinite adjustment up to 1.4" displacement
- same unit for driver or passenger seat
- round switch

N316-0683 Power 4-way Mechanical Lumbar

- rugged rear mount hybrid spring frame
- infinite adjustment up to 1.4" displacement
- vertical position adjustment up to 2"
- same unit for driver or passenger seat
- 2 round switches

**SH-ISCF** Vented Seat Cooling System

- circulates cooler air from floor thru seat
- 4 high power fans
- requires full perf leather
- use with die cut split pad heater
- round switch with icon ~ Hi/Lo/Off

## AC003-M Vibra Massage

- 6 motors, install into seat foam
- multi-level, multi zone vibration massage
- 15 minute time-out
- round switch with icon

